

NO-DRILL BRACKET PART# 221000
COMPONENT BREAKDOWN



#1
6 pcs

#2
6 pcs

#3
4 pcs

#4
2 pcs

NO-DRILL BRACKET PART# **221000**

2001+ ACURA MDX / 2003+ HONDA PILOT

A. FRONT BRACKET



PICTURE# 1



PICTURE# 2

1. Look for the location of the front pair of plugged existing holes right next to the pinch weld area. Remove the plugs to reveal the existing holes (Picture# 1). Install Bracket# 1 onto these existing holes using the provided bolts (metric thread) and washers.
2. Look for the existing holes on the bottom of the main frame/chassis area that align with the pinch weld area holes. Install Bracket# 2 onto these existing holes using the provided bolts and washers.
3. Install Bracket# 3 onto Bracket# 1&2, making sure that the resulting bracket assembly is perpendicular to the body and level horizontally.

B. MIDDLE BRACKET



PICTURE# 1

1. Look for the pair of plugged existing holes right next to the pinch weld area towards the middle of the vehicle (Picture# 1) and follow the same instructions for the front bracket.

C. REAR BRACKET



PICTURE# 1



PICTURE# 2

1. Look for the pair of plugged existing holes right next to the pinch weld area towards the rear of the vehicle (Picture# 1) and follow the same instructions for the front bracket. Be sure to use the special bracket with the additional box extension, Bracket# 4 instead of Bracket# 3.

NOTE: For reference, the following is a photo of the group assembly, driver side.

