

NO-DRILL BRACKET PART# FOEXPL
COMPONENT BREAKDOWN



#1
2 pcs
(shorter bracket)

#2
4 pcs
(longer bracket)

#3
6 pcs

NO-DRILL BRACKET PART# FOEXPL 02-06 FORD EXPLORER 4 DOOR

A. FRONT BRACKET



PICTURE# 1



PICTURE# 2



PICTURE# 3

1. Look for square hole with a round hole right beside it (Picture# 1), towards the upper part of the opening between the frame and the body behind the front wheel of the vehicle (Picture# 3). Insert Bracket# 3 into the square hole lining up the nut welded on Bracket# 3 with the round hole (Picture# 1).
2. Insert a bolt with a lock washer and washer to the top hole of Bracket# 1 (Bracket#1 is the shorter bracket) and tighten down to the nut of Bracket# 3 (Picture# 2). Make sure to clear all existing cables and tubes.

3. Look for existing round hole on the pinch weld area in line with the upper square and round holes. Insert a bolt from the upper part of the pinch weld hole through the second hole of Bracket# 1 and tighten down with a washer, lock washer, and nut (Picture# 2).

B. MIDDLE BRACKET



PICTURE# 1



PICTURE# 2

1. Look for set of existing holes as in the front bracket, this time in the area right after the front door (Picture# 1).
2. Follow the same installation instruction as in the front bracket, this time using Bracket# 2 (Bracket# 2 is the longer bracket). See Picture# 2 for reference. Make sure to clear all existing cables and tubes.

C. REAR BRACKET



PICTURE# 1



PICTURE# 2

1. Look for set of existing holes as in the front bracket, this time in the area right before the rear wheel (Picture# 1).
2. Follow the same installation instruction as in the front bracket, this time using Bracket# 2 (Bracket# 2 is the longer bracket). See Picture# 2 for reference. Make sure to clear all existing cables and tubes.