

**NO-DRILL BRACKET PART# GMALL7
COMPONENT BREAKDOWN**



OEM STYLE CUSTOM BRACKETS, 6 PCS.
BOLT PLATES, 6 PCS.
NUTS W/ WASHERS & LOCK WAHSERS, 6 PCS.
REGULAR BOLTS W/ WASHERS & LOCK WASHERS, 6 PCS.

Note: Each bracket is the same for all 6 locations.

NO-DRILL BRACKET PART# GMALL7 07-09 ALL CHEVY SILVERADO / GMC SIERRA

REPRESENTATIVE INSTALLATION



1. Start with the driver side front location. Above the pinch weld area, there will be a plugged big hole to the right of a smaller hole. Remove the rubber plug from the big hole and slip in the Bolt Plate into the big hole with the threaded portion going out of the smaller hole. (Note: In some earlier batches, the plate of the bolt plate may need to be cut about 3/8" shorter on the longer end in order to go into the bigger hole.) Hold onto the threaded portion of the bolt plate so that it does not fall down into the double wall area.
2. Loosely put on a washer, lock washer, and bolt onto the bolt plate.
3. Slip the bracket on top of the bolt plate with the washers in front of the bracket and loosely tighten the nut to hold the bracket in its relative position.
4. On the pinch weld area, align the bracket hole with the hole aligned to the top hole. Install a bolt through then put a washer, lock washer, and nut into it. Do not fully tighten.

5. Repeat the above steps for all the other 5 bracket locations.
6. Once all the brackets have been installed, put a flat ruler over all three brackets on one side of the vehicle to make sure that they are aligned. Once aligned, fully tighten all the nuts holding the vertical part of the brackets in place. Repeat the process for the other side of the vehicle.
7. Install the running boards onto the brackets.